

## Accessory Listing

Power Supplies – these are needed to provide the Cranesmart System with +12VDC > +36VDC required for normal operation. We have many models in stock to meet your power conversion requirements

Batteries – long life lithium ion packs – includes instructions, allen key, new gasket and sealant

Solenoid directional control valves – required to shut down crane functions – we stock models to meet most crane requirements

Extra winch kit (counterweight & chain)

Audible overload alarm for load monitoring system

Offset link for load cell – for those tricky dead end placements

Extension jaw for load cell – for use in some headache balls where the becket attaches inside the ball

Rock solid carrying case – carrying convenience for system components

12 Volt battery pack and smart charger – for remote operation of panel

Power cables made to custom lengths

Spare antenna parts

External magnetic mount for 10” rubber antenna

Long range metal antenna – magnetic mount

Mounting bracket for receiver panel

Weld plate with allen bolts for A-2-B switch attachment

Quick release weld plates with security pin

Becket pins

By-pass keys for A-2-B Panel